
Datacolor 200



Datacolor® 200 User Guide
Part No. 019-400019, Rev A

All efforts have been made to ensure the accuracy of the information presented in this format. However, should any errors be detected, Datacolor appreciates your efforts to notify us of these oversights.

Changes are periodically made to this information and are incorporated into forthcoming versions. Datacolor reserves the right to make improvements and/or changes in the product(s) and/or program(s) described in this material at any time.

© 2016 Datacolor. Datacolor, Datacolor 200, SPECTRUM and other Datacolor product trademarks are the property of Datacolor.

Microsoft and Windows are either registered trademarks of Microsoft Corporation in the United States and/or other countries.

To obtain information on local agents, contact either of the offices listed below, or visit our website at www.datacolor.com.

Support Questions?

If you need help with a Datacolor product, please contact one of our top-rated technical support teams listed in the appendix for the Datacolor office in your area.

Below is contact information for local Datacolor offices:

US (Lawrenceville, NJ)	Datacolor	+1 800 982 6496
Europe (Belgium, Netherland and Luxembourg)	Datacolor België BVBA	+32 9 243 87 27
Europe (France, Paris)	Datacolor SAS	+33 148185 480
Europe (Germany, Marl)	Datacolor Marl	+49 2365 510950
Europe (Italy)	Datacolor Italy SRL	+ 39 0362 332142
Europe (Switzerland and Other Countries Including Middle East & Africa)	Datacolor AG Europe	+41 448353711
Europe (United Kingdom)	Datacolor Ltd	+44 1619299441
Asia (China Hong Kong)	Datacolor Hong Kong	+852 2420 8283
Asia (China, Shanghai)	Datacolor Shanghai	+86 21 5308 6988
Asia (India, Mumbai)	Datacolor Mumbai	+91 22 6640 4488
Asia (Taiwan & Taipei)	Datacolor Taiwan	+886 2 2321 2356
Latin America (All Countries Except Brazil)	Datacolor & Local Agents	+1 800 982 6496
Latin America (Brazil)	Datacolor & Local Agents	+55 119996-8479 +55 1197095-9434

Email Addresses

Asia	ASPSupport@datacolor.com
Europe, Middle East and Africa	EMASupport@datacolor.com
North and South America	NSASupport@datacolor.com

CONTENTS

Datacolor 200	1
About Datacolor 200	1
Electrical/Environmental Requirements	1
Safety Warnings.....	1
Feature Summary	2
Accessories.....	2
About This User's Guide	3
Cable Installation	4
Cables	4
Cable Installation.....	5
Controls and Indicators	6
Status Panel	6
Powering Up.....	6
Instrument Calibration	7
General Calibration Information.....	7
Datacolor 200 Setup and Calibration	8
Instrument Setup for Datacolor PAINT	8
Datacolor PAINT Instrument Calibration	9
Setup and Calibration for Other Datacolor Programs.....	9
Sample Presentation and Measurement	13
Sample Viewing Port	14
Maintenance	15
Sphere Cleaning	15
Tile Handling and Cleaning.....	15
Appendix	17
Datacolor 200 Instrument Specifications	17
Miscellaneous Technical Information.....	18

This page intentionally left blank

Datacolor® 200

About Datacolor 200



Datacolor 200 is a member of the newest generation of Datacolor bench top color measuring instruments. Incorporating state-of-the-art CMOS integrated circuit technology in the instrument design, it is intended for use as a device for measuring, specifying and evaluating color in both laboratory and retail settings.

Electrical/Environmental Requirements

Power	100 – 240 VAC 50 to 60 Hz 1 A
Absolute Operating Environment	5° to 40° C 20-85% RH, non-condensing Altitude up to 2,000 meters

Safety Warnings

If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.



There are no user-serviceable parts for this equipment

Light Source

Do not stare directly into the open port located in the front door panel when the measurement is in progress. Staring directly into the light source can result in eye discomfort similar to that caused by staring at a camera flash.

Power



Disconnect power before servicing.
The power cord supplied with the unit must be used.

Feature Summary

Datacolor® 200 employs state-of-the-art features including the spectrometer, integrating sphere, light source, and optics. Below is a summary of those features:

FEATURE	DESCRIPTION
Integrating sphere	Barium coated sphere
Measurement Geometry	D/8° geometry, specular component included (SCI) or excluded (SCE).
SP2000 Spectral Analyzer	Proprietary dual-channel holographic grating. 256-photodiode linear arrays used for both the reference and sample channels.
Light source	Pulsed xenon flash lamp
Wavelength Resolution	2 nm
Reporting Interval	10nm

Accessories

All models come with the following standard accessories:

- Power cable
- USB cable
- Black trap
- White tile
- Green tile
- Memory stick



NOTE

A serial cable for the instrument is available for purchase.

Calibration Tiles

A black trap, white tile and green tile are provided with Datacolor 200.

- The black trap and white tile are used each time the instrument is calibrated.
- The green tile is used during calibration to perform a diagnostic test.



The calibration accessories are located in a drawer at the base of the instrument, and should be kept there when not in use.

Aperture Plates

Datacolor® 200 is a single aperture instrument. However, a variety of aperture sizes are available to accommodate different applications. Consult with a Datacolor representative to determine the correct aperture size for your application.



NOTE

Appendix, [Instrument Specifications](#) provides details about the aperture sizes available for Datacolor 200.

About This User's Guide

This guide is provided in a PDF format for easy access. To return to the page previously viewed when using the hyperlinks, press the following key combination:


<ALT> <left arrow key>

Cable Installation

Cables

 **WARNING**
Turn off power **BEFORE** working with any cables.

Datacolor® 200 requires the use of two cables, a power cable and an instrument cable that connects the instrument to the computer.



 **WARNING**
Refer to [Electrical/Environmental Requirements](#) before connecting the instrument.

The connections for these cables are located on the back of the instrument.



Power Cable

A six-foot power cable is provided with the instrument.



Power is supplied to the back of the unit via a 3-prong male connector.



 **WARNING**

The power cord supplied with the unit *must* be used.

Instrument Communications Cable

The instrument is connected to a computer through a USB port.

USB Cable Connection



 **NOTE**

A serial connection can also be used to connect to the instrument. A serial cable is available for purchase.

Cable Installation

1. Plug the female end of the power cord into the power receptacle on the rear panel of the instrument. Insert the plug into a standard AC outlet.
2. Connect the instrument cable to the appropriate connector on the rear panel of the instrument.
3. Connect the instrument cable to a communications port on the back of the computer.



4. Tighten each connection securely to ensure proper signal.

 **NOTE**

When the connection is made and the program is launched, the instrument will be detected automatically.

Controls and Indicators

Status Panel

The status panel indicates the current instrument settings being used. Below is the status panel for the Datascolor® 200:



OPTION

Calibration. Indicates if the calibration interval has expired.

Red. Calibration has elapsed. Recalibrate the instrument before using to ensure an accurate measurement.

Green. Instrument is calibrated.

Service. Indicates when the instrument should be serviced.

Amber. Annual service check is recommended.

Green. Instrument is performing properly.


Powering Up



WARNING

The power cord supplied with the unit *must* be used.

1. Verify all cable connections.
2. Plug the AC power cord into an outlet.
3. Attach the instrument cable to the instrument, and to a port on the computer
4. Turn on the computer.
5. Turn on the power switch. It is the red switch on the back of the instrument.
6. When power is applied, all mechanisms are automatically reset.



NOTE

If the instrument is not turned on before you launch a Datascolor program, you may receive an error message.

1. When the front panel Calibration LED remains lighted, your instrument is ready to be calibrated.
2. Launch a Datascolor program.

Instrument Calibration

General Calibration Information

Datacolor® 200 must be calibrated regularly to ensure that the measurements are accurate. This section provides instructions for installing the calibration data and performing the calibration. Below are instructions for performing the calibration using [Datacolor PAINTE](#) and [other Datacolor programs](#).

Reflectance Calibration

The instrument measures the reflectance of an object. It should be calibrated periodically to compensate for changes in the environment. A black trap, white tile and green tile are included with the instruments.



The software prompts for instrument calibration vary slightly from one program to another. However, you are always required to measure the black trap, white tile and green tile to complete the calibration.



NOTE

The recommended calibration interval may vary depending upon the Datacolor application that you are using.

Calibration Data

The calibration data for the instrument is stored on the instrument before it is shipped. The program you run will automatically find it during the first instrument calibration. A backup copy of this data is included on the memory stick provided with the unit.

Datacolor® 200 Setup and Calibration

The first time you launch a Datacolor program, you must add the instrument to the system. When running Datacolor PAINT, the program *automatically detects and configures* the instrument for use with the program.

If you are using Datacolor TOOLS, Datacolor MATCH and other Datacolor programs, you must provide inputs for the program to configure the program to recognize the Datacolor 200. See [Instrument Setup and Calibration for Other Datacolor Programs](#) for step-by-step instructions.

You will need the black trap, white tile and green tile to complete the calibration. They are located in the instrument accessory drawer.


Accessories




Instrument Setup for Datacolor PAINT

When you launch Datacolor PAINT for the first time, the program automatically detects the Datacolor 200 and configures the program to use it.

1. Launch Datacolor PAINT and select **Custom Color Match**. Initially, there will not be any information displayed in the Instrument Information box and the *Calibration Status* will be red.



2. The program will locate the instrument and the screen will display information about the instrument that is connected. The *Calibration Status* will be **red**.
3. Click on the **Calibrate** button and calibrate the instrument before you continue. The *Calibration Status* will turn **green**.



The next section provides instructions to complete the instrument calibration.

Datacolor® PAINT Instrument Calibration

When the *Calibration Status* button is red, you should calibrate the instrument before making any measurements. The calibration routine consists of measuring the black trap, white tile and green tile. They are stored in the accessory drawer.


CAUTION

When the *calibration status* is red, the instrument will not operate. You must calibrate the instrument to make a measurement.


1. Click on the **Calibrate** button.

The program will prompt you to measure the black trap, white tile and green tile.

1. Start with the black trap. Position it at the port and press **Ready**. When the measurement is completed, repeat this procedure for the white and green tiles.



2. When the green tile measurement is completed, the program displays information about the measurement.



3. Click **Ok**. The program stores this as the master measurement for the green tile. You can now measure samples.



NOTE

Each time the instrument is calibrated, the current green tile measurement is compared to the stored value. When there are significant differences between the current measurement and the stored value of the green tile, the service indicator will turn amber, indicating that service is required.

Setup and Calibration for Other Datacolor Programs

When using programs other than Datacolor PAINT, you must add Datacolor 200 to the instrument list. Below is the procedure for Datacolor TOOLS. This procedure is used for all Datacolor programs *except Datacolor PAINT*.

Instrument Setup


1. Launch the Datacolor® program and enter the user name and password.




2. The main program window will display. Select the **Instrument Calibration** option.



3. Select **Calibration**. The measurement main window displays:




4. Click **Add**. The Add Instrument window displays.




5. **Display** the drop down menu in the *Model* field, and scroll to Datacolor 200.


6. **Select** Datalogic® 200. The *Port* field will display auto-select.



7. Click **Add**. The program will search for the device and display the com port assignment:




8. Click **Add**. Datalogic 200 will display as the current instrument. At the bottom of the window, the program will display information about the instrument selected:



9. Click **Close**. The Measurement Main Window displays. You can now calibrate the instrument.


Instrument Calibration

1. Navigate to the Measurement Main window, and select **Calibrate**.




The program will prompt you to measure the black trap, white tile and green tile.

2. Start with the black trap. Position it at the port and press **Ready**. When the measurement is completed, repeat this procedure for the white and green tiles.



3. When the green tile measurement is completed, the program displays information about the green tile measurement.



4. Click **OK**. The program stores this as the master measurement for the green tile. You can now measure samples.

Sample Presentation and Measurement

When measuring samples using Datacolor® 200, you must pay close attention to the positioning of the sample to insure an accurate measurement. When positioned correctly, the sample rests between the sample holder and the front panel door. The sample must completely cover the aperture opening.

To position the sample:

1. Grasp the sample holder and pull forward.



2. Position the sample at the port.



3. Return the sample holder to the upright position.



 **WARNING**
Do not allow the sample arm to spring back.

Sample Viewing Port

When measuring small samples, you may need to verify that the correct area of the sample is being measured.

To check the sample area being viewed by the lens:

1. Grasp the tab above the aperture plate.



2. Pull the tab down to its full horizontal position. Look at the backside of the door to see the area of the port opening that is covered by the sample.



If necessary, adjust the placement of the sample to properly position the sample area to be measured. The sample must completely cover the port opening.

3. Push the door back to its normal position, and start the measurement.



Maintenance

The sections that follow provide detailed instructions for maintaining Datacolor® 200 and calibration tiles. These instructions and tips will help to insure that the instrument continues to perform properly over its life.

 **CAUTION**

There are no user-serviceable parts for this equipment.

Sphere Cleaning

The sphere should be examined visually for the presence of dust, sample particles, fibers, and excessive yellowing due to environmental influences. *This inspection should be performed frequently, especially if you measure loose materials.*

 **NOTE**

If you discover loose materials in the sphere, contact Datacolor Service for instructions to remove the loose material.

Tile Handling and Cleaning

Handling Tiles

- Handle calibration tiles with extreme care. Do not drop them, or scratch the glazed surface.
- Always grasp the tile using its edges.

Cleaning Tiles

- The calibration tiles should be cleaned before each use. Wipe each tile clean with a soft, lint-free cloth.



- A detergent, free of optical brighteners, fluorescent materials or photoactive dyes should be used as needed to clear any oils, fingerprints, or other deposits.
- Liquid dish detergent is a suitable detergent. The detergent/water solution should be prepared as follows:

1 part detergent: 250 parts water

- Use a few drops of the detergent solution to moisten a soft, lint-free cloth, and gently wipe the tile surface. Rinse the detergent from the tile by wiping it with a cloth, moistened with clean water.
- **NEVER** use abrasive cleansers, razor blades, or other metal objects to remove dirt or foreign substances from the calibration tiles. This will damage the tile surface.
- **NEVER** immerse the tiles in water.
- Tiles that have scratches, chips, abrasions or cracks must be replaced. Signs of wear on the tile surface will affect the accuracy of the calibration.

Tile Storage

- Large temperature variations will affect the accuracy of your calibration, requiring more frequent calibration. The calibration tiles should be stored in an environment that simulates the temperature of the samples to be measured.
- Prolonged exposure to sunlight or other sources of ultra-violet radiation will cause the color of the tiles to change. The tiles should always be stored in a protective case or container away from direct sunlight and environmental contaminants.

Cleaning the Black Trap

- The black trap should be kept dust-free. Dust accumulating in the black trap should be blown out with compressed air. The compressed air ***must be free of moisture***.



Appendix

Datacolor® 200 Instrument Specifications

Specifications are subject to change without notice.

ITEM	DESCRIPTION					
Instrument Type	Dual beam integrating sphere with xenon flash lamp.					
Measuring Geometry	Diffuse illumination, 8° viewing in conformance with CIE publication No. 15.2 Colorimetry.					
Illumination Source	Pulsed xenon, filtered to approximate D65.					
Spectral Analyzer	Proprietary SP 2000 analyzer with dual 256-diode array and high-resolution holographic grating.					
Wavelength Range	400 – 700nm					
Reporting Interval	10nm					
Wavelength Resolution	2nm					
Photometric Range	0 to 200%					
Photometric Resolution	0.003%					
Aperture Configuration	Large Area View		Small Area View		Ultra-Small Area View	
	Illuminated 22mm	Viewed 18mm	Illuminated 9mm	Viewed 5mm	Illuminated 6.5mm	Viewed 2.5mm
Power	100 to 240 VAC, 50 to 60 Hz, 1 A					
Performance— Repeatability*	0.05 CIELAB Max on white ceramic					
Performance—Reproducibility*	0.2 CIELAB ΔE average of 12 BCRA tiles					
Absolute Operating Environment	5° to 40° C, 20-85% RH, non-condensing Altitude up to 2,000 meters					
Interface	USB v2.0 ~or~ (Optional) RS232 9600/19200 baud					
Warranty	One Year					
Dimensions with Drawer	English			Metric		
Height	8.5 inches			21.59 cm		
Width	6.7 inches			17.01 cm		
Depth	11.1 inches			28.23 cm		
Weight	12 lbs.			5.44 kg		

* Specification based on following environmental conditions: 20°C; 50% RH; 2 sigma

Miscellaneous Technical Information

Datacolor® 200 RS-232C Connector Pin Assignments

Pin #	Purpose	Direction
2	Transmit data	Out (to host)
3	Receive data	In (from host)
7	Signal ground	

 **WARNING**

- (1) *DO NOT WIRE* to pins other than 2, 3, and 7.
(2) For all unused inputs, the default is active high.
-